

Flip Alarm Clock

Item # PI-1309

Instruction Manual

Features

One side of the clock is engraved with a "clock" icon and the other with an "alarm" icon

To activate the alarm, place the "alarm" side face up and the LED backlit display shows both current and alarm time.

To turn the alarm off, simply flip the clock so the "clock" icon is facing up and only the current time will display.


- Alarm turns on and off with flip movement
- Blue backlit display
- Large easy to ready LCD
- 12/24 hour selectable mode
- Easy to set time and alarm
- Perfect travel companion – compact & lightweight

Batteries: 2 'AAA' (not included)


Dimensions: 5" x 3.3" x 1.2"

Weight: only 3 ozs.!


1. Functions



Clock mode – Clock icon faces up
The time display is 6:30



Alarm mode – Alarm icon faces up
The alarm display is 5:00




① Battery Cover – insert 2 AAA batteries (not included)
② HR: Adjust hours ③ MIN: Adjust minutes
④ SET: Time set

2. Batteries


Insert 2 'AAA' batteries into the battery compartment and ensure the polarity (+ -) is correct. The clock will beep which indicates it is working. When the LCD display or backlight is weak, you have to replace the batteries.

3. Setting – Time & Alarm

(1) Time setting



(2) Alarm clock setting



The clock is 12/24 hours selectable.. Press the "SET" button for 3 seconds until the time on the LCD starts flashing.

Then press the "SET" button again to enter into select mode. Press the "+" or "-" on "HR" or "MIN" button to select setting.

4. Alarm & Backlight Function

The alarm will beep for 2 minutes continuously if not turned off. Simply flip the clock so the clock icon is facing upward to stop the alarm. To activate the LCD backlight, simply shake the clock slightly and the light will turn on.